



1. Location of Central Meter Pole shall be determined by a representative of Pioneer Electric Cooperative.
2. Contribution In Aid of Construction (CIAC) charges shall be paid in advance per Policy 8H (Schedule of Fees).
3. Pioneer will install a 30 foot, Class 4 pole, one ground rod and ground wire on pole, service drop clevis and metering. All other required equipment and conductors beyond the Point of Delivery shall be furnished and installed by the member or contractor.
4. The pole shall be owned and maintained by the member and tagged as a "Consumer Owned Pole". Pioneer shall own and maintain the current transformer and metering.
5. The disconnect shall be rated at 200 or 400 ampere. If a stand-by generator is to be used, a double throw switch must be used.
6. Disconnect can be mounted on the top of the pole (as shown) or can be mounted at meter level.
7. The Central Meter Pole must be kept clear and accessible to Cooperative employees at all times.
8. Approved and released by local regulatory agency before permanant connections are made.

PIONEER RURAL ELECTRIC CO-OP., INC. PIQUA, OHIO 45356		
Central Meter Pole For Service To Multiple Locations		
Oct. 2004	Rev. 6/2005	PRE 8